




# Crime Prevention Products

Copsham House, 53 Broad Street  
Chaesham, Buckinghamshire HP5 3EA  
Tel : 01494 792592 Fax : 01494 792590




## Keyless Door Lock


- (A) Slide
- (B) Serrated Edge
- (C) Finger Points
- (D) Tongue
- (E) Base




Place tongue in door latch recess found in door frame.




Close Door, making sure Keyless Door Lock is firmly in place.



Holding Base, firmly push slide forwards until firm.



You will now find the door is completely secure.



To release the Keyless Door Lock, press firmly on front of slide and pull back, via the knob.

